







ARATA



ASSEMBLY INSTRUCTION


ARATA HB39A-Q




ASSEMBLY INSTRUCTION

ARATA HB39A-Q


PARTS




① x 1




② x 1




③ x 2 (Left - Right)




④ x 1



⑤ x 2



⑥ x 2 (Left - Right)




HARDWARE



φ12x50mm

Ⓐ x 4



Ⓑ x 4



M8x25mm

Ⓒ x 32



Ⓓ x 32



Ⓔ x 4



Ⓕ x 4

TOOL



M5x65mm


Ⓖ x 1




Ⓗ x 1

ASSEMBLY INSTRUCTION


ARATA HB39A-Q



STEP 1




STEP 2




ASSEMBLY INSTRUCTION


ARATA HB39A-Q



ASSEMBLY INSTRUCTION
ARATA HB39A-Q








ARATA



ASSEMBLY INSTRUCTION


ARATA HB39A-K




ASSEMBLY INSTRUCTION

ARATA HB39A-K


PARTS




① x 1



② x 1




③ x 2 (Left - Right)




④ x 1



⑤ x 2



⑥ x 2 (Left - Right)




HARDWARE



φ12x50mm

① x 4




② x 4



M8x25mm

③ x 32



④ x 32




⑤ x 4



⑥ x 4

TOOL



M5x65mm


⑦ x 1




⑧ x 1

ASSEMBLY INSTRUCTION


ARATA HB39A-K



STEP 1




STEP 2




ASSEMBLY INSTRUCTION


ARATA HB39A-K



ASSEMBLY INSTRUCTION
ARATA HB39A-Q








ARATA



ASSEMBLY INSTRUCTION


ARATA HB39A-CK




ASSEMBLY INSTRUCTION

ARATA HB39A-CK


PARTS




① x 1



② x 1




③ x 2 (Left - Right)




④ x 1



⑤ x 2



⑥ x 2 (Left - Right)




HARDWARE



φ12x50mm

① x 4



② x 4



M8x25mm

③ x 32



④ x 32




⑤ x 4



⑥ x 4

TOOL



M5x65mm


⑦ x 1




⑧ x 1

ASSEMBLY INSTRUCTION


ARATA HB39A-CK



STEP 1




STEP 2



ASSEMBLY INSTRUCTION

ARATA HB39A-CK



ASSEMBLY INSTRUCTION
ARATA HB39A-CK

